



Mounting information

- 1) Drill the handle housing according to the template dimensions reported in the table.
- 2) Remove all drilling burrs before fitting the handle.
- 3) Fit the upper part of the handle into the housing.
- 4) Press onto the lower part until the handle is completely inserted.

Identification no. 1	for $b_1 = 90$		for $b_1 = 110$		for $b_1 = 120$	
	$x \pm 0,2$	$y \pm 0,1$	$x \pm 0,2$	$y \pm 0,1$	$x \pm 0,2$	$y \pm 0,1$
Wall thickness s						
0,7 ... 0,8	85	34,9	100	49,7	107,5	70,5
> 0,8 ... 1,2	85	35,1	100	50	107,5	70,8
> 1,2 ... 1,5	85	36,1	100	50,4	107,5	71,2
> 1,5 ... 2	85	36,1	100	50,7	107,5	71,5
> 2 ... 2,2	85	36,1	100	50,7	107,5	71,5

Identification no. 2	for $b_1 = 110$		for $b_1 = 120$	
	$x \pm 0,2$	$y \pm 0,1$	$x \pm 0,2$	$y \pm 0,1$
Wall thickness s				
> 0,8 ... 1,2	100,2	50,5	107,5	71,3
> 1,2 ... 1,5	100	51,4	107,5	71,8