





-



<b>V</b>	9	
S	b	Length I
0,3	10	21
0,4	10	29
0,6	10	45
0,8	10	60

## Specification

Steel
Paulo
ROHS

The flat springs GN 374 are a perfect and virtually non-wearing connecting link between scale ring GN 264 and spindle or collar bushings GN 268. When adjusting the spindle, they ensure that the scale ring is safely driven without impairing the setting options of the ring when the shaft is at rest.

see also	Page
GN 264 Scale Rings	QVX
GN 268 Collar Bushings	QVX

1

How to order	1	S	5
GN 374-0,3-10	2	b	

1.4 Adjusting, Positioning, Locking with and without Position Indication