





1.1
1.2
1.3
1.4
2.1
2.2
2.3
2.4



Type **TG**
Oval head latch bolt




Type **TT**
T-head latch bolt




Type **TU**
J-hook latch bolt




Description of function (for one-hand operation)




Press the release button for **releasing**.




Lift the clamping arm until the latch bolt disengages from the catch.



Retracting the clamping arm will lift the latch bolt and release the catch (one-hand operation).



For **clamping operation**, lift the clamping arm until it rests on the catch.



The clamping arm engages in the catch if the release button is pressed for the clamping operation.

When clamping in the end position, the system locks automatically by spring force.

